



IP CAMERA

User Manual

IV-DV28122MP-AF

Auto Focus

V1.2

PRECAUTIONS

- Do not use the camera in extreme temperature conditions.

Please use the camera within 14°F to 122°F

Air vent is required at high temperature

- Do not use or store the camera in humid environment

It may cause poor image quality.

- Do not use the camera in unstable lighting conditions.

Inconsistent lighting or flickering may cause poor image.

- Never use the camera close to gas or oil leak.

It may not operate properly.

- Do not disassemble the camera.

There is no user serviceable part inside.

- Do not drop the camera or apply force on it.

It may cause a malfunction.

- Never face the camera to strong light for long periods of time.

It may damage the CMOS sensor.

When this camera is installed near wireless communication devices that emits strong electro magnetic field, irregularity such as noise may appear in the image.



1.OPEN-CASE INSPECTION

1.1 Check step

When a user receives a IP camera, Please check the equipment appearance without obvious damage. Product packaging use protective material to deal with most accidental impact in the transport process.

Please open the product outer packing,Check attachment provided product is complete,See List 1 below accessories package for inspection.

1.2 Standard accessories

Please make sure the item is consistent with the listing when open the product outer packing,Detailed list please see the table below,Actual configuration, please refer to specific products.


List 1 Accessories list

Name	Units	Quantity
IP camera	pcs	1
User Manual	pcs	1
Accessory pack	pcs	1
CD	pcs	1

2.PRODUCT STRUCTURE

2.1 Cable function

Picture 1 Cable function





List 2 Cable function of table

NO.	Name	Functional description
1	LAN	Connect to a router or switch on your network using RJ45 Ethernet cable (Cat5e or better). 100Mhz connection. PoE supported (class 3 PoE switch required).
2	RS-485	+: RS-485A -: RS-485 B
3	BNC	N/A
4	Audio output	Audio output
5	Alarm input/output	12: alarm input 34:alarm output
6	Audio input	Audio input
7	DC 12V	DC 12V input


2.2 Dimensions

Picture 2 Dimensions



3.EQUIPMENT INSTALLATION

Picture 3 Equipment installation diagram (1)



NO.	Name
1	IP Camera
2	Mounting Screw
3	Expansion bolt
4	Sticker
5	Wall or Ceiling

Description: bracket installation metope, need to withstand at least 3X the total weight of the bracket and the camera


3.1 Put stickers to the surface where need to be installed (Wall or Ceiling) ;

3.2 Carried out in accordance with the installation sticker above marked the location of the hole;

3.3 Open the accessory pack, take out expansion bolt, expansion bolt nail into drilled holes inside;

- 3.4 Open the attachment pack, take out the screws; With this screw will play good expansion bolt installation device fixed to the surface (wall or ceiling);
- 3.5 Plug the external cables according to the use requirements of equipment.

Picture 4 Equipment installation diagram(2)




- 3.6 Using tools to adjust screw loose device;
- 3.7 The up and down or so regulating equipment, according to the use requirements set equipment of direction;
- 3.8 Using tools to screw locking device;

4.Network Operation

- 4.1 Use correct power supply
- 4.2 After startup, connect the device with switch or router, see below picture

Picture 5 Network structure



4. 3 Default IP setting:
- IP address: 192.168.0.123
- Subnet Mask: 255.255.255.0
- Gateway: 192.168.0.123
- User name: admin
- Password: 123456

- 4.8 Open IE,type IP address.login with user name and password, see below picture.

Picture 8 WEB GUI After login, enter into below picture



Picture 9 WEB GUI after login



Equipment specific relevant parameter Settings please refer to IP camera user manual in the CD“IPCAM user manual V2.0.2.doc”.

5.SPECIFICATIONS

Model		IV-DV28122MP-AF	
Camera			
Image Sensor		1/3" 2 Megapixel SONY CMOS	
Effective Pixels		1920(H)x1080(V)	
Scanning System		Progressive	
Electronic Shutter Speed		Auto/Manual 1/50~1/10000	
Min. Illumination		Color: 0. 1 lux /F1.4, B/W: 0.01 lux /F1.4,0 lux (IR on)	
S/N Ratio		>50dB	
Camera Features			
Max. IR LEDs Length		90 ft	
Day/Night		Auto(ICR) / Color / B/W	
Backlight		BLC	
White Balance		Auto	
Gain Control		Auto/Manual	
Noise Reduction		3D	
Privacy Masking		Up to 4 areas	
Slow Shutter		None / Low / Middle / High	
Motion Detection		22X18 areas	
Lens			
Focal Length		2.8-12 mm (Auto Iris)	
Max Aperture		F1.2	
Mount Type		Board-in Type	
Video			
Compression		H.264 High Profile / JPEG Snapshot	
Resolution		60Hz Mode: 1080P(1920*1080) / 720P(1280*720)	
Frame Rate	Main Stream	1080P/720P (1 ~ 25 / 30fps)	
	Sub Stream	D1/CIF(1 ~ 25/30fps)	
Bit Rate		H.264: 50 K ~ 8000 Kbps	
Network			
Ethernet		RJ-45 (10/100Base-T)	
Protocol		IPv4, HTTP, SSL, TCP/IP, UDP, UPnP, ICMP, IGMP, SNMP, RTSP, RTP, SMTP, NTP, DHCP, DNS, PPPOE, DDNS, FTP, IP Filter, QoS, Cloud	
ONVIF		ONVIF Ver. 2.0	
Max. User Access		5 users	
Smart Phones		iPhone, Android	
Browsers		IE	
General			
Power Supply		DC12V, PoE (802.3af)	
Power Consumption		<10W	
Working Environment		Temperature: 14°F~140°F, Humidity: 10%~90%	
Ingress Protection		IP66	
Dimensions		5.81" x 4.82"	
Weight		Appro 2.65 lbs	

The Specifications are subject to change without prior notice.